

Operating Manual MINIPAN® 350V

updated: 2016-10-07-Fz

- Universal Digital Panel meter




Table of contents

1	Display and operating elements	3
2	Factory-preset:	3
3	Application and short description	3
4	Overview of functions	3
5	Connection plan	4
6	Important notes	5
7	Assembly	5
8	Putting into Operation	5
9	Setting of Parameters:	6
9.1	Line-Resistance at version for Pt 100-sensors (RTD):	7
9.2	Measuring Unit (°C or °F) at version for Pt 100-sensors (RTD):	7
9.3	Indication of the digital display:	8
10	Operation	9
10.1	DC- and AC-Meters	9
10.2	Operation Pt 100- Meter	9
11	Trouble shooting	10
12	Form	12

1 Display and operating elements

1. Digital display with 4 digits
2. Button "Up"
3. Button "Set/Reset"
4. Button "Down"
5. Decimal point behind last digit:
 - off = display mode (measured values)
 - on = menu mode, select the menu items
 - blinking = parameter setting mode



2 Factory-preset:

Reset to factory setting: Push button Set for 10 s when applying supply voltage until "----" is displayed.

Parameter	Version			Users own Data
	MINIPAN DC	MINIPAN AC	MINIPAN Pt 100	
InPU	10	1	-	
L-R	-	-	3-L	
Unit	-	-	°C	
ScAL	Auto	Auto	-	
InLo	0.00	0.000	-	
InHi	10.00	1.000	-	
d,Lo	0	0	-	
d,Hi	5000	5000	-	
dP	0000.	0000.	-	
dd, S	0.5	0.5	0.5	
F,	F,	F,	-	
Code	oFF	oFF	oFF	
P, n	504	504	504	

3 Application and short description

With its 4 digit, 14 mm high display, Digital Panel meters of MINIPAN 350 V- series allow the accurate display of different values in the range -1999 ... +9999.

Only 3 designs cover the measuring of DC voltage and current, AC voltage and current and temperature with Pt 100- sensors (RTD).

The display can be easily programmed by the customer (e.g. input 0-10 V --> display 0-350.0 ms or AC 0-1 A ---> 0- 400.0 A

With the built-in universal power supply AC/DC 24-240 V it is especially versatile.

4 Overview of functions

Easy programming with 3 buttons:

- Display (scaling, decimal-point)
- Display of MIN- and MAX-values
- Delay for display at unstable signals
- Code-lock against manipulation of settings
- Terminals pluggable
- Face-Plate 36 x 72 mm

5 Connection plan

Inputs DC-Meter:


- Measuring of current with external shunt max. 300 mV
- 1 A for direct measuring of current
- 0/4-20 mA for standardsignals
- 0-10 V for standard-signals
- 100/500 V switchable

Inputs AC-Meter:

- 500 V
- 50 V
- 10 V
- Measuring of current with external shunt max.150 mV
- 1 A for direct measuring of current or with external transformer

Measuring of Temperature Pt 100 (RTD)

- Pt 100 in 2- or 3-wire connection
- Measuring Range -199,9 ... +850,0 °C
- Resolution 0,1 °C
- Display in °C or °F



6 Important notes



ATTENTION

Dangerous electrical voltage!
May lead to electrical shock and burn.
Before beginning of work switch unit and equipment free of voltage.

Only let persons work with the equipment who are familiar with installation, start and use and who have appropriate qualification corresponding to their function. They must observe the contents of the instructions manual, the information which are written on the equipment and the relevant security instructions for the setting up and the use of electrical units.

The equipments are built according to DIN / EN and checked and leave the plant according to security in perfect condition.

If, in any case the information in the instructions manual is not sufficient, please contact our company or the responsible representative.

Instead of the industrial norms and regulations written in this instructions manual valid for Europe, you must observe the valid and relevant regulations of the corresponding country.



The **measuring inputs** is are insulated from supply-voltage but not from each other. **Connect one input only!**

Universal power supply.

The device has got a universal power supply, that is suitable for DC- and AC-voltages. Before connecting the device to supply-voltage make sure that the connected voltage corresponds with the voltage on the type plate on the device.

7 Assembly

- Installation in switchgear cabinet on 35 mm mounting rail according to EN 60715
- With screws M4 for installation on walls or panel. (additional latch not included in delivery)

8 Putting into Operation

Connect supply-voltage Us.

Connect signal to measuring input. **Connect one input only!**

9 Setting of Parameters:

Decimal point behind last digit:

- off = display mode (measured values)
- on = menu mode, select the menu items
- blinking = parameter setting mode

9.1 Display Mode

Display of actual measured value.

Function buttons Up/Down

- Push short Change to menu mode, selection of menu item
- Push for > 2 s Display of stored MIN- or MAX- values

Function of button Set /Reset

- Push short no function
- Push for > 2 s Reset of MIN- or MAX-value (with Min- or Max-button pushed simultaneously)
- Push for > 10 s Display of software-version

9.2 Menu Mode (Decimal point behind last digit ON)

Selection of the menu items for changing the parameters.

Function buttons Up/Down

- Push short Selection of menu item; Change into display mode

Function button Set/Reset

- Push short Change into parameter setting mode

9.3 Parameter setting mode (Decimal point behind the last digit FLASHES)

Function buttons Up/Down

- Push short/long Adjustment of parameter value (slow/fast)

Function button Set/Reset

- Push short Storage of setting and choice of next parameter.
Change into menu mode after the last parameter

Parametrizing of Input / Measuring Range

Select menu item with Up/Down until display I_{nPU} and measuring range alternate.

Change into parametrizing mode with Set and select measuring range with Up/Down.

Confirm and change to next menu with Set.

When changing measuring range parameters for scaling the display are set to:

$$I_{nLo} = 0\%, I_{nHi} = 100\% \text{ of measuring range, } d_i L_i = 0, d_i H_i = 5000 \text{ und } dP = 0000.$$

Scaling the Display

Select menu item with Up/Down until display S_cRL and mode (AUTO or USER) alternate.

Change into parametrizing mode with Set and select mode with Up/Down.

AUTO: Display = measured signal without scaling.

USER: Range of input-signal and range of display can be set by the user. The range of the input-signal must be within the measuring range.

Examples:

	InPU	ScAL	InLo	InHi	dL0	dLH	dP
Input 0..10 V Display 30..100 %	10	USEr	0.00	10.00	30	100	0000.
Input 4..20 mA Display 0..100 %	4-20	USEr	4.00	20.00	0	100	0000.
Input 0..20 mA Display 50.0..500.0	0-20	USEr	0.00	20.00	500	5000	0000.0
Input 10..90 V Display 50.0..500.0	100	USEr	10.0	90.0	500	5000	0000.0
Input 0-60 mV Display 0,0..30.0	300	USEr	0	60	0	300	0000.0
Input 2..5 V Display -50.0..100.0	10	USEr	2.00	5.00	-500	1000	0000.0

Confirm and change to next menu with Set.

Delay of Display (recommended at unstable signals)

Select menu item with Up/Down until display d_d 5 and programmed value alternate.

Change into parametrizing mode with Set and set delay of display with Up/Down.

Now the measured value will be written into the display every 0,1 ... 2 s.

Confirm and change to next menu with Set.

Fixed Digits (recommended when measured signal is very unstable or changing rapidly)

Select menu item with Up/Down until F and the fixed digits blinking are displayed. When no fixed digit is programmed, the last 2 digits are dark.

Set the fixed digits:

F₁ no

F₁ 0 last digit fixed (0)

F₁ 00 last digit fixed (00)

These digits display 0, independent from measured value.

Confirm and change to next menu with Set.

Code-lock

Select menu item with Up/Down until display Γ_{odE} programmed state alternate.

Here the parameters can be protected by activating the code-lock. After pushing Set, P_{1 n} is displayed.

Change to P_{1 n} 504 with buttons Up/Down (factory setting). After pushing Set the code-lock can be activated or de-activated. After pushing Set again, an individual P_{1 n}

Can be selected (write down)

With activated code-lock, all parameters can be seen but not changed any more.

In case of problems with the code-lock (forgotten P_{1 n}), the lock can be switched off and the P_{1 n} can be set back to 504, by pushing the button Set/Reset while connecting the device to supply voltage until Γ_{odE} / oFF is displayed.

Line-Resistance at version for Pt 100-sensors (RTD):

Select menu item with Up/Down until display L-R and programmed parameter alternate.

Change into parametrizing mode with Set and do the line-compensation with Up/Down (enter value of line-resistance) or 3-wire (3-L).

2-wire-configuration, compensation of cable-resistance:

Short-circuit the wires nearby the sensor and measure the resistance of the cable. Set „LR“ to this value.

Measuring Unit (°C or °F) at version for Pt 100-sensors (RTD):

Select menu item with Up/Down until display U_n E and programmed unit alternate.

Change into parametrizing mode with Set and select unit (°C or °F).

9.4 Tips:

- After finishing one menu item it is switched automatically to the next one.
- When the right decimal point in the 7 segment display is on, the display mode has been left, and the menu items can be chosen with up/down (menu mode).
- When the right decimal point blinks, you are in the parameter setting mode and can change the setting with up/down.
- Long pushing on up/down speeds up the changes in the display.
- Pushing button up and down at the same time sets values to zero.
- With reset (press set/reset for 2s) the display mode can be reached from every position of the parameter setting mode (the last selected value in is being stored).
- With I_{nLo} and I_{nHi} scaling is simplified when measuring-range and range of signal are different.

Example: Display 0-500.0 at input-signal 10-90 V:


- Connect to measuring input 100 V and select $I_{nPU} = 100$
- Set I_{nLo} to 10.0
- Set I_{nHi} to 90.0
- Set d_{iLo} to 0
- Set d_{iHi} to 5000
- Set dP to 000.0

9.5 Indication of the digital display:


I_{nPU}	= measuring input / measuring range
500	= 500 V
100	= 100 V
50	= 50 V
10	= 10 V
300	= 300 mV
150	= 150 mV
0-20	= 0-20 mA
4-20	= 4-20 mA
1	= 1 A
S_{cRL}	= scaling of measuring range and display
RU_{to}	= Zero, FullScale and decimal-point are taken over from selected measuring range
USE_r	= scaling of measuring input and measuring range by the user
I_{nLo}	= measuring range - Zero
I_{nHi}	= measuring range - FullScale
d_{iLo}	= displayed value at measured signal = I_{nLo}
d_{iHi}	= displayed value at measured signal = I_{nHi}
dP	= decimal point
dd_{iS}	= delay of display
F_i	= fixed digits
$CoDE$	= code
Pin	= factory-setting of Pin = 504
on, off	= an / off
L-R	= wire compensation
3-L	= 3-wire
$Unit$	= measuring unit for temperature Pt 100 (°C, °F)
====	= Min
	= Max
$ErLo$	= input current <3,8 mA at measuring range 4-20 mA
$Er8, Er9$	= error in device
-EEE	= signal lower than measuring range / display range
EEEE	= signal higher than measuring range / display range

10 Operation

10.1 DC- and AC-Meters



10.2 Operation Pt 100- Meter



11 Trouble shooting

- Unit cannot be programmed – Code lock
The code lock gives protection against unauthorized manipulation of the unit. When code lock is activated the parameters can not be changed. The pin can be set by the user.
Pin unknown? Make code-reset: When switching in supply-voltage keep pushed button „Set“ for **2 s**.
Display indicates: "8888"; "Code"; "OFF"; "8888" release button „Set“.
Code = OFF, Pin = 504.
- Indicated temperature does not correspond to the sensor temperature
Is the correct measuring unit selected (°C or °F)?
Check programmed sensor-connection (2- or 3-wire, line-resistance).
- Displayed value wrong or no signal
Check if the correct input is selected and if the signal is connected to the correct terminals.
Check if terminals have been plugged correctly.
- Display „ErrLo“
input current <3,8 mA at measuring range 4-20 mA. Check lines for break.
- Display „ErrB“ „ErrG“
ErrB and ErrG are internal errors (hardware / parameters). Switch off and on supply-voltage and reset parameters to factory-setting.
If the error still exists send it back to factory for repair.
- Display „-EEE“
signal lower than measuring range / display range.
- Display „EEEE“
signal higher than measuring range / display range.
Display of software-version: push Set for >10 s in display mode

12 Technical data

Power Supply

Rated supply voltage Us	AC/DC 24-240 V
Tolerance DC	DC 20 - 297 V (0,85 x 24 V...1,35 x 220 V)
Tolerance AC	AC 20 - 264 V (0,85 x 24 V...1,1 x 240 V)
Power consumption	< 3 VA
Frequency	48...62 Hz

Measuring Inputs

DC-Meter

Measuring range / resistance of input
/ overload capacity

AC-Meter

Measuring range / resistance of input
/ overload capacity

Measuring time AC/DC

Pt 100- Meter

Sensor-connection

Wire-resistance 3-wire

Measuring time temperature

insulated from supply-voltage
(connect 1 input only)

± **300 mV** / 120 kΩ / max. ±2,5 V

± **10.00 V** / 1 MΩ / max. ±50 V

± **500.0 V** / 3 MΩ / max. ±600 V

± **100.0 V** / 3 MΩ / max. ±600 V

± **20.00 mA** / Shunt 15 Ω / max. ±100

± **1.00 A** / Shunt 150 mΩ / max. ±2 A

150 mV / 900 Ω / max. 2,5 V

10.00 V / 100 kΩ / max. 50 V

50.0 V / 1 MΩ / max. 60 V

500.0 V / 3 MΩ / max. 600 V

1.00 A / Shunt 150 mΩ / max. 2 A

< 400 ms + delay of display ddi 5

- **199,9 ... + 850,0 °C** (= -328 ... +1563 °F)

Pt 100, 2- or 3-wire

max. 3 x 50 Ω

< 400 ms + delay of display ddi 5

Accuracy

Resolution	+9999 / -1999
Accuracy (of full measuring range)	
DC voltage and current	± 0,1 % ± 1 Digit
AC voltage and current	± 0,5 % ± 1 Digit
Temperature factor	± 0,02 % / Kelvin
Accuracy Pt 100- Meter	± 0,3 % of value ± 0,5 K
Temperature factor	± 0,03 °C / K

Test conditions

Measuring category	EN 50178 / EN 61010-1 EN 61326-1 industrial applications CAT II 600 V DOUBLE INSULATION CAT III 300 V DOUBLE INSULATION
Contamination level	2
On-time	100 %
Rated ambient temperature range	-20 °C ... +60 °C EN 60068-2-1 dry heat
Vibration resistance EN 60068-2-6	2...25 Hz ±1,6 mm 25 ... 150 Hz 5 g


Housing

Design V2, switchgear mounting	
Mounting height	55 mm
Width	2 TE
Dimensions (width x height x depth)	35 x 90 x 58 mm
Wire connection, one wire	each 1 x 0,5...1,5 mm ²
Stranded wire with insulated ferrules	each 1 x 0,14...1,0 mm ²
Protection class housing	IP 30
Protection class terminal	IP 20
Installation	Snap mounting on mounting rail 35 mm according to EN 60 715 or with screws M 4
Weight	approx. 120 g

Subject to technical changes

13 Form

Dimensions in mm



- 1 Cover
- 2 Base
- 3 Bar for snap mounting
- 4 Latch for sealing
- 5 Front panel
- 6 Position downward
- 7 For fixing to wall with screws, \varnothing 4,2 mm.